

INSTALLATION INSTRUCTIONS

102016 TPS-TEC™ THROTTLE ENHANCER

GM CARS 1982-1989:

VIN O 82-86

VIN P 83-86

VIN U 82-86

VIN L 85-88

VIN 7 86-89

VIN 8 82-84

VIN 2, R 82-86

VIN B, 3 87-88

VIN 7, S 82-83

1. REMOVE CONNECTOR FROM TPS BY PRYING UP ON LOCKING CLIP.

2. INSERT TPS-TEC CONNECTORS BETWEEN EXISTING CONNECTIONS OF CAR WIRING AND TPS.

THROTTLE POSITION SENSOR (TPS)

3. TURN IGNITION KEY TO "ON" BUT DON'T START CAR. "STANDBY" LED SHOULD BE ILLUMINATED.

4. MOVE THROTTLE AS IF YOU WERE ACCELERATING VEHICLE. THE "ENHANCE" LED INDICATOR SHOULD ILLUMINATE.

