

INSTALLATION INSTRUCTIONS

103011 Oval Harness Conduit - 1986-1987 turbo 3.8 GN/Ttype

This conduit is supplied in a longer section than is required for the turbo engine harness. You must cut the conduit to length and cut a notch into one end of the slit side to permit positioning of the ground wires and the positive feed wires that run down to the starter. See illustration below:

