



ECUgn add on harness pinouts Added to part number 109030

10 Pin Connector Located Passenger Side by Relays - Underhood	Wire Color	Function	Where it goes
A	WHT/RED	AUX	Screw Down Ferrule
B	WHT/BRN	AUX	Screw Down Ferrule
C	WHT/GRN	AUX	Screw Down Ferrule
D	WHT/ORG	AUX	Screw Down Ferrule
E	BLK	GND for 5V Sensors	ECM C1
F	GRY/WHT	+5V Supply	ECM C2
G	ORG	High Current 3 Output	ECM C9
H	PPL	Spark C	ECM B1
J	YEL	Analog IN 3 (0-5V)	ECM B11
K	BLU	User (PWM 3)	ECM D4

These connections pass thru to the 10 pin connector located under hood, passenger side, by the relays. The connector is a sealed 10 pin metripack connector with a dust cap (in case these accessories are not used). If you populate the mating connector - which is provide in the kit - simply remove the seal plug and insert your terminal. This terminal is designed for 18 gauge wire.

Also integrated into this harness is the wideband O2 connection. This is the small 6 pin connector located at the ecuGN, and the O2 sensor connector is underhood, located by the relays, and is the "D" shaped connector.

If you have any questions, please do not hesitate to contact us! We'll be happy to help!