

INSTALLATION INSTRUCTIONS

102071 SCHRADER TEE

DESIGNED TO ACCESS FUEL THROUGH THE SCHRADER TAP FOUND ON THE FUEL RAIL OF THE ENGINE. THE FEMALE PART OF THIS TEE INCORPORATES A VALVE RELEASE PIN WHICH OPENS THE VALVE IN THE FUEL RAIL FITTING. **ALWAYS CHECK FOR LEAKS DURING AND AFTER INSTALLATION OF THIS TEE. DO NOT OVERTIGHTEN BRASS FITTINGS!**

